



In case of RCF:

Squawk 7600. Climb FL070 straight-ahead to intercept and proceed R357 ESP DVOR/DME. At 7 DME ESP DVOR/DME turn left to intercept and proceed R065 ESP DVOR/DME. At 27 DME ESP DVOR/DME turn left to intercept and proceed R188 FTM DVOR. At 49 DME FTM DVOR turn left to intercept and proceed QDR103° LAR NDB holding. Complete one holding pattern descend to 4000 ft to perform another LOC approach.

MAG VAR changed. New RWY designator.

THIS PAGE INTENTIONALLY LEFT BLANK