



In case of RCF:
Squawk 7600. Climb FL070 straight-ahead to intercept and proceed R094 LIS DVOR/DME. At 24 DME LIS DVOR/DME turn right to intercept and proceed R188 FTM DVOR/DME. When crossing R070 ESP DVOR/DME turn right to intercept and proceed R073 ESP DVOR/DME to ADSAD holding. After completing one holding pattern proceed on track 281° to PT422 (R167 14.4 DME CAS DVOR/DME). Turn right on track 025° to PESEX (R151 11.0DME CAS DVOR/DME) descending to 4000 ft to perform another ILS approach.

Procedure description corrected.

THIS PAGE INTENTIONALLY LEFT BLANK